



HD Portable Satellite System SM00575 / 82985

Satellite list / Channel list UPGRADE procedures – Internet Webpage download

Note: You will need a USB memory stick or portable flash drive / hard disk (Removable Disk))



1. Before switching on your satellite system
2. Download the file from the webpage by left clicking on the file [UPG_DG_180327.ddf](#)
3. Open the USB stick / storage device and copy the downloaded file onto the USB stick file (Root path / flash drive/portable hard disk (Removable Disk)) (Do not copy into a folder or Directory)
4. Making sure your satellite system is off
5. Plug the USB storage device into the receiver (Right hand side). And then turn on the Satellite receiver.
6. On the Remote Control press the [MENU] key then looking at the left hand side of the screen push the down arrow key [v] (Below OK Button) to highlight the 'Tools' Icon.
7. Press the right hand key [>] (Next to OK Button).
8. Then use down arrow key [v] (Below OK Button) to highlight the Upgrade by USB option, press the [OK] Key.
9. Use the Left [<] and Right Key [>] (Either side of the OK Key) to set the Upgrade Mode option to indicate 'DDF'.
10. After the confirmation that the file name shown is correct then press "Start" to initialize the upgrading procedure. Please refer to the three photographs below.





11. After the upgrade is successfully installed (this will take about a minute Do NOT switch off the unit while the upgrade is taking place). Select the 'Factory Setting' option this will refresh the satellite list data. If you have set the Password Enter it to proceed with the Factory Reset (refer to the user manual if you are in doubt on the Password setting) otherwise ignore this step. Please refer to the three photographs below.





- Unplug the mains power to turn the receiver completely OFF and then restart the receiver by plugging it in again. Now when it reboots/ starts the receiver will have the latest satellite list loaded.

